

# **NexaVM - Supermicro Motherboard RAID Operation Guide V1.0**

Document Version: V1.00

Email [support@nexavm.com](mailto:support@nexavm.com)

Website <https://www.nexavm.com>


Address Via Serafino Balestra 27 6900 Lugano (Switzerland)

# 1 Table of Contents


1	Table of Contents .....	2
1.	Chapter 1 — BIOS Configuration.....	3
1.1	Enable RAID on SATA System Disk.....	3
1.2	Save with F4, Restart the Device, and Access Intel VROC .....	3
	.....	4
1.3	Enter the Intel VROC Page and Configure RAID Members .....	4
1.4	Successful Creation .....	5
1.5	Save, Exit BIOS, and Install the Operating System .....	6

# 1. Chapter 1 — BIOS Configuration


## 1.1 Enable RAID on SATA System Disk




## 1.2 Save with F4, Restart the Device, and Access Intel VROC



### 1.3 Enter the Intel VROC Page and Configure RAID Members



#### 1.4 Successful Creation



### 1.5 Save, Exit BIOS, and Install the Operating System